


Basic Wireless Router

WNR612

Package Contents:




Ethernet Cable



Power Adapter

Step 1: Connect your modem.




CAUTION:
MAKE SURE YOUR MODEM IS
TURNED OFF OR UNPLUGGED
BEFORE STARTING THE
INSTALLATION.

Step 4: Power on your modem. Wait until your modem cycles on (approximately 2 minutes).

Note: If you have a battery-backed modem, press the reset button. (In some cases, you may need to remove, then re-insert, the battery to recycle your modem.)

Step 2: Connect your router.



Step 5: Power on your router. Wait until the power LED turns solid green.

Step 3: Connect your computer.

Step 6: Configure settings. Open a browser, such as Internet Explorer, and enter www.routerlogin.net to complete the setup.

